

1. Install Mortise Lock

Inside

See template for door prep specifications

2. Mount Inside and Outside Trim to Door

Outside

Inside

Plates and grip vary depending on style.

3. Install Key Cylinder

Install Key cylinder by threading it clockwise onto trim plate.

4. Tighten Key Cylinder

After key cylinder is installed, secure cylinder by tightening screw

5. Install Trim Plate

6. Tighten Inside Lever or Knob

Inside

Tighten Lever with 3/32 Hex wrench (provided).

7. Install Door Jamb

See template for door jamb prep specifications